

playmobil®

3632



30 00 515



30 14 050



30 11 033



30 08 033

30 08 034

30 80 088

30 66 238



30 05 366



30 08 032





30 07 319

30 08 028



30 08 029



30 07 380

9

30 07 379

8

30 07 378

7

30 08 030

6

30 07 377

5

30 07 376

30 08 021

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L' adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Direcciones de Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.