





playmobil®

3717


⚠ WARNING:
CHOKING HAZARD - SMALL PARTS.
Not for children under 3 years.

Ne concerne que les USA





30 80 744



30 03 683




30 08 675




30 06 622



30 07 368




30 00 570



30 00 569



30 14 064



30 00 571



30 64 818



30 64 817

Serviceadressen finden Sie in allen Playmobil-Prospekten
Addresses of Customer Service Departments are shown in all Playmobil catalogues
L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil
Direcciones de Departamentos de Servicio al Consumidor se encuentran en todos los catalogos Playmobil
Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.

playmobil