



**WARNING:**  
 CHOKING HAZARD - SMALL PARTS.  
 Not for children under 3 years.  
 \*Ne concerne que les USA\*



30 08 840

30 08 830




30 06 021

30 06 043

30 06 044

30 05 123



30 04 006


30 08 841

30 07 055


30 07 054

30 82 279

30 82 280



30 60 605




30 63 103

30 03 887


30 08 825

30 05 099





30 66 434



30 08 842



30 14 066



30 11 049



30 10 072



30 11 050



30 60 514




30 06 778




30 07 533




30 05 098



30 64 918



30 61 079



30 61 078

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catalogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.

**playmobil**