


⚠ WARNING:

CHOKING HAZARD - SMALL PARTS.
Not for children under 3 years.


"Ne concerne que les USA"






30 88 584


30 02 890



30 02 885








30 02 914




30 02 910



30 02 908

30 06 946







30 61 229



30 02 920



30 61 042




30 66 016

30 07 384



30 07 382



30 07 368



30 09 661



30 61 217



30 03 115



30 02 943

Serviceadressen finden Sie in allen Playmobil-Prospekten

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Addresses of Customer Service Departments are shown in all Playmobil catalogues

Direcciones de Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.