



3955  
5711

**WARNING:**  
CHOKING HAZARD - SMALL PARTS  
Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important documents keep carefully!  
Documents importants conservez avec soin!



30 63 4700




30 03 2630




30 21 1250


30 02 9360




30 91 7440



30 91 7450




30 91 7460



30 08 7780

30 08 7770

30 08 7750



30 20 1650

30 80 5410

30 20 1160



30 11 1010



30 91 7470



30 91 7480



30 91 7490

30 23 5750




30 03 1950



30 91 7500

30 06 0020




30 91 7510

30 06 7290



30 66 0770



30 91 7520



30 10 1520



30 06 7680




2x 30 06 7700



30 46 1370




2x 30 46 1380



2x 30 46 1430




30 23 5760







30 91 7530





30 91 7540






30 91 7550



1





2




30 91 7610

2x 30 06 6840



2x 30 06 6850

30 89 9810



30 91 7620

30 02 2340



30 21 1090



30 21 1080



2x 30 21 9930



30 89 4780



30 91 7630

30 20 8450



30 88 9090



30 91 7640

30 22 8600




30 22 8640



30 91 7650



30 67 0950



30 91 7660

30 22 7770



2x 30 22 7700



30 13 0650



30 91 7670

30 91 7700




1



30 91 7690

2



30 91 9210



3



30 91 7680



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl