





playmobil®
4137

WARNING:
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !





D A CH L Nur Trinkwasser verwenden. Nach dem Spielen austrocknen lassen.

USA GB CDN M Use only tap water. Dry thoroughly after play.

F CDN B L CH N'utiliser que de l'eau potable. Faire sécher après chaque utilisation.

E MEX Utilizar solamente agua potable. Dejar secar antes de guardar.

NL B Enkel drinkbaar water gebruiken. Na het spelen laten drogen.

I CH Usare solo acqua potabile. Asciugare bene dopo ogni uso.

P Utilizar somente água potável. Deixar secar antes de guardar.

DK Anvend kun drikkevand. Lad det tørre ud når du er færdig med at lege.

N Kun drikkevann skal benyttes. Tørk opp etter at leken er ferdig.

S FIN Använd endast dricksvatten. Låt torka efter användandet.

FIN Käytä ainoastaan juomavettä. Anna kuivua leikin jälkeen.

H Kérjük kizárólag ivóvizet használnjon! Játék után ajánlott a termék kiszáritása!

CZ Používat jen pitnou vodu. Po hraní nechat vyschnout.

EST Kasutada üksnes joogivett! Mängimise järel kuivatada!

LV Izmantot tikai dzeramo ūdeni. Pēc spēlēšanās ļaut nožūt.

LT Naudokite tik geriamąjį vandenį. Pažaidus, išdžiovinkite.

M Uza ilma tajieb ax-xorb. Wara l-loghob hallih jinxef.

SLO V igračo vlivajte le pitno vodo. Po igri naj se igrača posuši.


SK Používať iba pitnú vodu. Po hre nechať vyschnúť.

PL Używaj tylko wodę pitną. Po zabawie pozostaw do wyschnięcia.

TR CY Sadece içme suyu kullanınız. Oyundan sonra kurumaya bırakın.

GR CY Χρησιμοποιείτε μόνο νερό βρύσης. Μόλις τελειώσετε, αφήστε το παιχνίδι να στεγνώσει εντελώς.

1




30 63 4792

2

2x

30 27 4080



30 25 2390



30 25 2400



30 25 2410



30 25 2440



30 25 2430



30 51 4420




2x

30 20 3920



30 20 4720



3

1



3x 30 25 2320

1



1


1

30 20 7570

30 09 2120




30 24 9810



4

30 22 0530

30 89 5932



2x




2x



30 09 2110



30 25 2970



5


30 25 2810



30 25 2830



30 25 8710



1

30 27 4090

30 27 4100

30 27 4110



2


30 27 4130



30 02 6640

30 02 6840

30 02 6830




30 20 8250



30 62 9152

30 10 2110




30 67 7640

30 20 8260



30 09 2320



30 51 3640

30 11 1510

2x 30 25 6590

30 51 3640



30 66 5940



30 27 4120

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil
pronounce: plāy-mō-bēēl