

playmobil
5012



Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important documents keep carefully!
Documents importants conservez avec soin!
Belangrijke documenten, bewaar deze zorgvuldig!








WARNING:
CHOKING HAZARD

Small parts. Not for children under 3 years.


"Ne concerne que les USA"






1







2








2






3











4




5




1





2



3






4




3


2x



1




4




30 26 9740

5




9



30 61 8660


2

30 61 8660















30 05 7540

3




30 21 7350









30 21 9482




2x 30 66 7770




30 20 5480



30 26 9470




3x 30 20 5490



30 20 6512




4x 30 06 7620




30 51 8670




2x 30 20 2942




2x 30 25 2880




2x 30 20 5510




2x 30 20 5500




30 06 2590



2x 30 21 9702




30 51 8550



30 05 9300




30 03 2410




30 04 6640



30 82 3682



30 81 1880




30 51 8640




3x 30 88 3522




3x 30 24 4160




30 26 9390



30 26 9780




30 24 3630




2x 30 22 2760




3x 30 21 7330



30 05 9410



30 26 9790



30 21 9682



30 21 9692



30 21 9242



30 65 8822



4x 30 82 2490



4x 30 23 7690



30 51 6080



30 27 0340



30 51 8650



30 27 0330



30 26 9650



4x 30 23 3160



30 09 0960



4x 30 20 6502



3x 30 63 5722



30 23 1330



2x 30 23 0130



2x 30 51 4010



30 89 5592



30 21 9262



30 89 5622



4x 30 04 3960



30 25 3160



2x 30 26 9830



64x 30 26 1780



8x 30 03 6600



12x 30 04 8770

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil


Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēel



© 2010 geobra Brandstätter, 90511 Zimndorf, Germany. No. 30 82 4952 08.10