


playmobil®

5301

WARNING:
CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.

Ne concerne que les USA



Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important documents keep carefully!
Documents importants conservez avec soin!




5301 + 7776 + 3x 7775





1

1







2






3







3




1




2





3





4








6






7










5x


1




2










1




2




3





4





1





2







15




6x


1





2




3




4




17









18




19












1

30 89 7522



30 51 2850

2




30 89 7402



30 00 1432




30 14 2470




2x 30 26 2000




6x 30 25 4140




4x 30 25 4150




30 24 9650




2x 30 05 7100




2x 30 24 9600




4x 30 26 2040




2x 30 26 2050




2x 30 26 2060




30 26 2010




30 05 7120




30 24 9840




30 24 9850



2x 30 45 4020




2x 30 45 4030




4x 30 26 2020




2x 30 26 2030




2x 30 24 9760



2x 30 22 1510



2x 30 05 9740




10x 30 24 9730



30 24 9780




30 24 9770




6x 30 24 9900



6x 30 24 9890



5x 30 24 9620




2x 30 24 9640



3x 30 24 9630



2x 30 25 5070



2x 30 24 9610




30 24 9910



6x 30 05 7240



10x 30 24 9740



10x 30 24 9750



6x 30 24 9870



6x 30 24 9880



12x 30 05 7280




2x 30 05 7290



30 05 7270




6x 30 05 9810



5x 30 24 9790



12x 30 05 7320



5x 30 05 7520



2x 30 22 1500



6x 30 05 7310



7x 30 05 7300



30 05 7460



5x 30 24 9810



12x 30 05 7490




10x 30 24 9800



22x 30 24 9580



4x 30 05 7470



2x 30 60 8390



4x 30 05 7480



2x 30 26 1980




2x 30 26 1990



18x 30 24 9820



24x 30 05 9720




24x 30 24 9230




18x 30 24 9220




6x 30 24 9860




30 88 0032




30 88 0012




30 88 0042




30 88 0062



30 88 0002



30 88 0022




30 88 0052



30 88 0082



30 88 0072



30 89 7382

Serviceadressen finden Sie in allen Playmobil-Prospekten	Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil
Addresses of Customer Service Departments are shown in all Playmobil catalogues	Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil
L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil	Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil pronounce: plāy-mō-bēēl