



playmobil®


5339



30 05 973



30 05 871





30 06 249



30 05 742





30 08 574











30 65 936

30 05 942





30 08 579



Serviceadressen finden Sie in allen Playmobil-Prospekten	Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil
Addresses of Customer Service Departments are shown in all Playmobil catalogues	Direcciones de Departamentos de Servicio al Consumidor se encuentran en todos los catalogos Playmobil
L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil	Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.

playmobil®