



WARNING:
CHOKING HAZARD - SMALL PARTS.
Not for children under 3 years.
Ne concerne que les USA



1












2



3







30 05 212



30 66 016



30 10 081



30 14 091



30 14 092



30 09 683



30 09 684



30 09 677




30 09 678



30 07 101



30 09 681



30 80 535




30 09 676



30 09 679



30 09 680



30 09 682



30 06 118



30 06 314

30 06 030

30 06 731

30 02 967

30 08 050

30 07 340

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L' adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.