






playmobil®


5343

⚠ WARNING:
CHOKING HAZARD - SMALL PARTS.
Not for children under 3 years.


"Ne concerne que les USA"









30 09 465




30 09 520




30 05 973




30 06 249




30 05 871



30 04 193



30 05 972



30 08 567



30 05 742



30 09 212

30 09 211



30 06 093

30 05 742



30 06 093


30 06 092





30 60 661



30 09 706



30 60 841



30 07 096



30 08 574



30 09 707



30 08 575



30 06 114



30 05 594

30 06 317



30 14 006

30 05 578



30 14 093



30 09 627



30 09 624




30 65 060



30 09 705



30 66 216



30 80 535

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L' adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησως Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil.