

playmobil®

5424

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important: Please keep these instructions for future reference !
Documents importants, à conserver soigneusement !
Belangrijke documenten, bewaar deze zorgvuldig !



WARNING: CHOKING HAZARD

Small parts. Not for children under 3 years.

"Ne concerne que les USA"



(D) **(A)** **(CH)** **(L)** **(B)** Nur Trinkwasser verwenden. Nach dem Spielen austrocknen lassen.

(USA) **(GB)** **(CDN)** **(M)** **(IRL)** Use only tap water. Dry thoroughly after play.

(F) **(CDN)** **(B)** **(L)** **(CH)** N'utiliser que de l'eau potable. Faire sécher après chaque utilisation.

(E) **(MEX)** Utilizar solamente agua potable. Dejar secar antes de guardar.

(NL) **(B)** Enkel drinkbaar water gebruiken. Na het spelen laten drogen.

(I) **(CH)** Usare solo acqua potabile. Asciugare bene dopo ogni uso.

(P) Utilizar somente água potável. Deixar secar antes de guardar.

(DK) Anvend kun drikkevand. Lad det tørre ud når du er færdig med at lege.

(N) Kun drikkevann skal benyttes. Tørk opp etter at leken er ferdig.

(S) **(FIN)** Använd endast dricksvatten. Låt torka efter användandet.

(FIN) Käytä ainoastaan juomavettä. Anna kuivua leikin jälkeen.

(H) Kérjük kizárólag ivóvizet használgjon! Játék után ajánlott a termék kiszáritása!

(CZ) Používat jen pitnou vodu. Po hraní nechat vyschnout.

(EST) Kasutada üksnes joogivett! Mängimise järel kuivatada!

(LV) Izmantot tikai dzeramo ūdeni. Pēc spēlēšanās ļaut nožūt.

(LT) Naudokite tik geriamąjį vandenį. Pažaidus, išdžiovinkite.

(SLO) V igračo vlivajte le pitno vodo. Po igri naj se igrača posuši.

(SK) Používať iba pitnú vodu. Po hre nechať vyschnúť.

(PL) Używaj tylko wodę pitną. Po zabawie pozostaw do wyschnięcia.

(TR) **(CY)** Sadece içme suyu kullanınız. Oyundan sonra kurumaya bırakın.





(GR) **(CY)** Χρησιμοποιείτε μόνο νερό βρύσης. Μόλις τελειώσετε, αφήστε το παιχνίδι να στεγνώσει εντελώς.

(RO) Se folosește doar apă potabilă. După joacă se lasă să se usuce.



(BG) Използвайте само питейна вода. След игра оставете да изсъхне.

(CN) 仅使用饮用水. 玩耍后要干燥.


1






2




3





4



5



6



30 00 2533




30 14 6160



30 11 2570




30 10 3070



30 25 6642



30 25 6652



30 25 6632



30 07 3760




30 07 3770



30 07 3780



30 07 3790



30 07 3800



30 26 3100



30 26 0490





30 89 0972



30 25 6742



30 25 6662



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl