

playmobil®

5529




WARNING:
CHOKING HAZARD




Small parts. Not for children under 3 years.

"Ne concerne que les USA"




Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!





1



2




3





4



1










2





5









3




4




1




2






3












1




2







30 22 1513




30 22 1173



30 45 4900



30 22 1533



30 22 0803




2x 30 22 1503



30 20 9082




30 29 9420




30 82 6833



30 25 6150



30 45 6750



30 45 6940



30 22 1553



2x 30 28 6200



30 29 0950



4x 30 28 3180



2x 30 22 0793




30 60 3452



30 22 0823



30 22 0813




5x 30 22 1363



2x 30 22 1373




30 22 5920



2x 30 22 1183



30 22 1453



30 22 1393



30 22 1333



3x 30 02 3900



30 02 4190



30 23 1102



30 20 5780



2x 30 22 1523



2x 30 22 1543



30 22 1403



30 27 6910



30 02 6730



30 25 9003



30 21 3602



2x 30 22 1413



5x 30 22 5602



2x 30 21 4422



3x 30 20 5192



30 21 4552



30 63 1074



30 21 0203



30 25 6240



2x 30 25 6070



2x 30 22 1343



30 22 2812



30 21 0113



30 67 4392



30 25 9600



30 22 1293



30 51 4150



30 60 3442



30 20 5540



30 25 0610



30 09 6260




30 24 4740




30 28 7090



30 24 4730



16x 30 09 6900



16x 30 03 6600



30 62 6113



30 64 6493



30 62 8380



30 45 4590



30 45 6310



30 51 3880



30 26 9650



4x 30 05 7420



30 09 5540



30 24 1352



30 24 2452



30 24 2422



30 83 0440



30 28 5350



2x 30 22 1383



30 22 0783



30 22 0773



30 09 4750



30 22 1273



3x 30 23 8670



30 27 8300



30 25 5250



2x 30 88 8712



2x 30 28 4850



30 28 5410



30 22 0530



30 23 7992



4x 30 22 5859



12x 30 24 9230




12x 30 04 1939



6x 30 24 9829



30 22 0733



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

