

playmobil®

6104




WARNING:

CHOKING HAZARD - SMALL PARTS
Not for children under 3 years.

"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren !
Important documents keep carefully !
Documents importants conservez avec soin !
Belangrijke documenten, bewaar deze zorgvuldig!



30 64 9142

30 03 8000



1



30 22 0300

30 22 8010



30 64 5432

2




30 20 4730




30 20 4720







30 24 1620



30 24 1610



30 27 7090



30 25 0610

30 25 0600

30 25 0580

30 64 0352

1



30 51 3800

30 61 6580

30 51 3800

2



30 61 6580

30 25 5810

D A CH L B Nur Trinkwasser verwenden.
Nach dem Spielen austrocknen lassen.

USA GB CDN M IRL Use only tap water. Dry
thoroughly after play.

F CDN B L CH N'utiliser que de l'eau potable.
Faire sécher après chaque utilisation.

E MEX Utilizar solamente agua potable. Dejar secar antes
de guardar.

NL B Enkel drinkbaar water gebruiken. Na het spelen
laten drogen.

I CH Usare solo acqua potabile. Asciugare bene dopo
ogni uso.

P Utilizar somente água potável. Deixar secar antes de
guardar.

DK Anvend kun drikkevand. Lad det tørre ud når du er færdig
med at lege.

N Kun drikkevann skal benyttes. Tørk opp etter at leken er
ferdig.

S FIN Använd endast dricksvatten. Låt torka efter
användandet.

FIN Käytä ainoastaan juomavettä. Anna kuivua leikin jälkeen.

H Kérjük kizárólag ivóvizet használjon! Játék után ajánlott a
termék kiszárítása!

CZ Používat jen pitnou vodu. Po hraní nechat vyschnout.

EST Kasutada üksnes joogivett! Mängimise järel kuivatada!

LV Izmantot tikai dzeramo ūdeni. Pēc spēlēšanās ļaut nožūt.

LT Naudokite tik geriamąjį vandenį. Pažaidus, išdžiovinkite.

SLO V igračo vlivajte le pitno vodo. Po igri naj se igrača posuši.


SK Používať iba pitnú vodu. Po hre nechať vyschnúť.

PL Używaj tylko wodę pitną. Po zabawie pozostaw do
wyschnięcia.

TR CY Sadece içme suyu kullanınız. Oyundan sonra
kurumaya bırakın.

GR CY Χρησιμοποιείτε μόνο νερό βρύσης. Μόλις
τελειώσετε, αφήστε το παιχνίδι να στεγνώσει εντελώς.

CN 仅使用饮用水。玩耍后要干燥。



30 60 6690



2x 30 21 1302



30 25 5830




30 24 1630



30 88 1222

30 22 8000



30 14 3800



30 62 3130



30 00 7682



30 21 1432

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl

© 2009 geobra Brandstätter, 90511 Zirndorf, Germany.
No. 30 82 1472 07.09