

**playmobil®**

6872  
6919




**WARNING:**  
**CHOKING HAZARD**

Small parts. Not for children under 3 years.


"Ne concerne que les USA"

Wichtige Unterlagen, bitte sorgfältig aufbewahren!  
Important: Please keep these instructions for future reference!  
Documents importants, à conserver soigneusement!  
Belangrijke documenten, bewaar deze zorgvuldig!





6872



6919















3






4










5















6








7








8




9








10





11









12






13





14






15







16













17






18







19



20







**1**

30 02 8422  
30 26 7350

**2**

2x 30 03 4630  
30 27 1060  
30 23 2870

30 02 8412

30 28 8930

30 03 4940

**3**

30 23 6832

30 03 0720

Step 1: A grey panel (30 02 8422) is being attached to a grey structure (30 26 7350) using a black pin.

Step 2: Two grey panels (30 03 4630) are being attached to a grey structure (30 27 1060) using a yellow screwdriver. A grey spring (30 23 2870) is also shown.




Step 3: A grey panel (30 02 8412) is being attached to a grey structure (30 28 8930) using a black pin. A grey spring (30 03 4940) is also shown.

Step 4: A grey panel (30 23 6832) is being attached to a grey structure (30 03 0720) using a black pin. An inset image shows the completed assembly.






6919












6872




6919













30 02 8442



30 02 8452



30 02 8542



30 02 8532



30 02 8642




30 28 9100



30 02 8512




30 02 8562




2x 30 02 8582



2x 30 02 8602



30 02 8522



30 02 8432




30 02 8572




30 20 9413




30 02 8462



30 02 8472



2x 30 02 8622



2x 30 61 4710



4x 30 22 2610



30 02 8392



30 20 8443



30 23 1712



30 23 1722



2x 30 23 5630



2x 30 20 8663



2x 30 20 8653



2x 30 25 2562



4x 30 24 3310





30 28 9060



2x 30 02 8652



2x 30 02 8592



2x 30 02 8612



30 23 7882



30 27 5500




30 02 5200



30 21 5250




30 21 7172



8x 30 03 2942



2x 30 02 8372




16x 30 03 6600



32x 30 09 6900




2x 30 02 8662



2x 30 02 8482



4x 30 03 2952



2x 30 02 8332



30 09 4330



30 02 8552



2x 30 24 7172



2x 30 28 1610



30 25 9003



30 03 2940



2x 30 02 0472



30 65 0153



30 05 4980



30 21 7333



4x 30 03 2932



30 08 4950



2x 30 22 2780



30 21 0950



30 09 4020



30 21 3060



3x 30 23 5392



30 26 4410



30 02 8382



30 03 6610



2x 30 23 5270



2x 30 89 5132



2x 30 27 4260



30 24 2523



30 25 5170



30 21 3110



2x 30 08 4220



30 27 2930



30 21 0540



4x 30 21 3850




2x 30 23 5260



30 20 9950



30 25 3243



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl

