


playmobil®

6978



Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
Belangrijke documenten, bewaar deze zorgvuldig!







WARNING:
CHOKING HAZARD



Small parts. Not for children under 3 years.

"Ne concerne que les USA"




1








2





3













7










9







10





11










5159
7350




- Nachrüstbar mit Unterwassermotor
- Compatible with the underwater motor (sold separately)
- Monteur submersible, vendu séparément, s'adapte sur ce bateau

12







30 82 7914



30 82 7934




30 82 7924



30 66 0890




30 03 4102




30 51 5532




30 03 4142



30 51 5602




30 03 4252




30 03 4012




30 03 4062



30 03 4272



30 51 5522




30 51 5542



30 03 4112



30 03 4042



30 03 4132




30 62 0435



30 66 3762



30 03 4072



30 03 4232




30 03 4182



30 03 4172



30 03 4192



30 03 4162



30 62 0445



2x 30 62 0455




30 25 5400



4x 30 03 3952




30 22 1020



30 03 4002



2x 30 60 2572



30 03 4122



30 03 4082



30 25 1753



30 04 4720




2x 30 24 9953



30 25 9003



2x 30 21 4972



2x 30 60 2562



30 23 7910



30 21 0520



30 21 7130



2x 30 03 4052



30 62 6063



2x 30 28 3070



2x 30 03 4242



30 05 9610



30 63 6593



30 03 4032



2x 30 26 9650



30 25 5490



2x 30 04 9322



30 22 7490



2x 30 21 6370



30 29 2590



30 24 4130



2x 30 06 7780



2x 30 25 1403



30 21 0990



2x 30 25 0113



30 03 3932



30 03 4022



2x 30 23 2860



30 21 0480



30 22 4020



30 21 0490




2x 30 23 5260




2x 30 24 1572




30 22 8250



4x 30 03 6600



6978 + 6983



Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounce: plāy-mō-bēēl



100%