

7415 + 3959


30 66 778 30 66 656 4 x 30 06 762 3 x 30 66 777 30 66 661 30 66 702 30 20 248 30 20 249 2 x 30 20 033

3 x 30 20 036

3 x 30 66 660 3 x 30 20 006 3 x 30 20 008 30 20 253 4 x 30 20 252 4 x 30 20 251 2 x 30 20 016 30 20 014 30 61 259 30 20 015









30 03 659 30 03 641 2 x 30 20 250 2 x 30 04 160 30 20 011 30 20 012

30 66 696 2 x 30 20 001 30 20 002 30 88 586 30 66 735 96 x 30 09 690 12 x 30 04 877 8 x 30 03 660




7415


7415 + 3959










4




5





6



Serviceadressen finden Sie in allen Playmobil-Prospekten	Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil
Addresses of Customer Service Departments are shown in all Playmobil catalogues	Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil
L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil	Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους pronounce: plāy-mō-bēēl