




playmobil®

7470


WARNING:
 CHOKING HAZARD - SMALL PARTS
 Not for children under 3 years.

"Ne concerne que les USA"


Wichtige Unterlagen, bitte sorgfältig aufbewahren !
 Important documents keep carefully !
 Documents importants conservez avec soin !
 Belangrijke documenten, bewaar deze zorgvuldig!



1



30 89 8552




2

30 25 7740




30 25 7700




30 62 9462



30 81 7412




3



30 20 1022

1



30 21 8230

2



30 62 9432



30 24 7520



30 25 7730



30 25 7750



30 21 0940



30 06 3500



30 67 9800



30 62 9442



30 21 7950



30 07 6420



30 20 5020



30 62 9452



30 88 0132



30 62 9422



30 21 7720



30 09 5700

Serviceadressen finden Sie in allen Playmobil-Prospekten

Addresses of Customer Service Departments are shown in all Playmobil catalogues

L'adresse du service consommateurs est indiquée dans tous les catalogues Playmobil

Troverete gli indirizzi dei centri di assistenza in tutti i cataloghi Playmobil

In alle PLAYMOBIL catalogi vindt u het adres van onze klantendienst.

Las Direcciones de los Departamentos de Servicio al Consumidor se encuentran en todos los catálogos Playmobil

Η διεύθυνση του Γραφείου Εξυπηρέτησης Πελατών είναι καταχωρημένη σε όλους τους καταλόγους Playmobil

pronounce: plāy-mō-bēēl